



# SENSOR MENU BUTTON


DEFAULT VALUES ARE DISPLAYED IN WHITE



# VIDEO MENU BUTTON



DEFAULT VALUES ARE DISPLAYED IN WHITE



DEFAULT VALUES ARE DISPLAYED IN WHITE

